

rsal air conditioner remote controller

## MODEL NO.: MODEL NO.: KT-BO3 KT-BO3

## **UNIVERSAL A/C REMOTE**

#### KT-B03 Model Code Table


		aux SMs		
AIRWELL	AW ≅₩	LG	LG	L.5
ALPIN	AP RP	MACQUAY	MQ	MQ
AUCMA	AC RE	MIDEA	MD	MD
AUX	AX AX	MITSUBISHI	МІ	MI
BOERKA	вк ∄к	PANASONIC National	PN	PN
CARRIER	CR [R	PHILCO	PC	PE
CHANGHONG	CH [H	ROWA	RW	RH
CHIGO	CG [5	SAIJO DENKI	SD	SD
CHUNLAN	CL [L	SHARP SAMPO	SP	SP
DAEWOO	DW 🚻	SAMSUNG	SS	5.5
DAIKIN	DK JK	SANYO	SO	20
Electrolux	EX EX	SHINCO	SC	SE
FRESTECH	FS F5	SWAN	SW	Su
FUJITSU	FT F;	TADIRAN	TA	18
GALANZ	GZ 52	TATUNG	TT	YY
GREE	GR 5₽	TCL	TL	T.L.
HAIER	HR HR	TOSHIBA	TS	7.5
HISENSE	нѕ ж5	TRANE	TR	T.R
HITACHI	ні Ж	Whirlpool	WP	uР
HUABAO	нв н₃	WINIA	WN	un
HUALING	HL XL	YINYAN	ΥY	Y Y
HYUNDAI	HD HD	YORK	ΥK	YK
JOHSON	JO 🏸	Other Brand	AL	8L
KELON	KL KL			

**Brand Universal** 

**✓** Select brands directly by LCD display

✓ Nice looking

**▼**So easy



**QUNDA® KT-B03** 

OK

Universal A/C remote control



MADE IN CHINA

## UNIVERSAL A/C REMOTE

# 


KT-B03 One for all brands Universal air conditioner remote confroller

#### **Product Description**

KT-B03 is the latest product of QUNDA, it is a brand universal remote with patent technologies which is invented by our engineers: Place batteries, it can work for almost all brands in the world without setting, It is the best choice for you to replace the remote.

Thanks you for choosing our remote, it is honored that we can provide conveniences for your life.

Please read this manual carefully before using, which will be a great help for you to use the remote control.



#### Setting

#### Select brands directly

- 1. Find out the brand code which is short for the brand from table list
- 2、Press and hold "SEL" key, release it when the code on LCD flashes. "-" key until the brand code appears 3、Repeat press "BRAND +" or
- 4、Press "OK" key, brand code stop flashing. Setting finishes.
- 5. If it does not work well, please aim to the air conditioner, press and hold "OK" key until air conditioner sends "buzzer" sound. After setting, check other function keys can work or not, if it works, setting succeed, if not, repeat above steps until it can use for your air conditioner.

#### Auto searching-1

- 1、Open air conditioner, put remote aim to A/C, press and hold "SEL" key until the brand code appears on LCD.
- 2. Press and release "SEL" until air conditioner send "BUZZER" sound, after release key, the code flashes.
- 3、Press 'OK" key, brand code stop flashing. Auto searching finishes. Check all other functions whether can work or not, if it does not work: repeat above steps until it can use for your equipment.

Auto searching-2 If you do not know the brand of your air conditioner, or if your brand is not listed in the code table, please operate as per following steps:

- Open air conditioner, aim at A/C, press and hold "OK" key
   Release "OK" key as quickly as air conditioner sends "BUZZER" sound 3. Check all other functions whether can work or not, if it does not work;

Setting

repeat above steps until it can use for your equipment.

#### Clock set up

- Press the "CLOCK" button, it is blinking.
  Press the "BRAND/TIME + or -", setting to the current time
- "CLOCK" button again, stop blinking, the time setting is Press the complete
- (If you did not press the "CLOCK" button, it can be setting automatically after 5 seconds)time and clock signal. Now setting is complete

### TIMER OFF

You should set the timer off after open the air conditioner.

Press the "TIMER off" button, the LCD displays the clock signal and

- 1, Press the
- time blinking.

  2. Press "BRAND/TIME + or -" button, adjust to the required time

  3. It will confirm the time of TIMER OFF after 5 seconds. Setting finishes.
- The time frame can be set between 00-24 hours;
- Press the "TIMER OFF" two times continuously, cancels the timing.
   If you want to see the timer off time, you only should press "TIMER OFF",
   Then It will show this time, and after 5 seconds, it will show current time again.
- 4. After timing setting, the launch direction of remote control must be aim at the receive direction of your air conditioner in the effective distance, otherwise the timing setting ineffectively.

#### Attention

- If it is not used for a long time, remove the battery to avoid leakage liquid of the battery to damage the machine. When the LCD looks dim, please change batteries. (New and old batteries can not be used together) After the batteries are replaced every time, it is not necessary to set model code again.

  2. Check carefully that there is no remora between remote controller and Air
- conditioner when the time off doesn't work. Because the operation is effective only when the air conditioner receives the timer off signal from remote controller.
- 3. The manufacturer keeps the right to change the parameter and function of product.

#### Technical Parameters

Controllable distance: Large than 8 meters (According to the machine) Battery model: Battery AAA(UM-4、R03) $\times$ 2

Dimension: L145mm×W53mm×D19mm Weight:Approx65g (excl.the batteries)

#### Manufacturer

Name: QUNDA Control Technology (Jiangsu) Co., Ltd.
Address: No.888 LongQiao Road, WuJiang District, SuZhou, China

Post code: 215200

Web site: www.qunda.com

 $\bigstar$  The final explanatory right is reserved this company. Any alteration on the design and model will not be further notified.